GENERAL NOTES:

1.) PLEASE REFERE TO RUM AND RUMXTREME INSTALLATION MANUAL FOR PROPER LAMPHOLSTER MOUNTING LOCATIONS.

2.) USE SUPPLED (2) #18 x 1" PAN HEAD PHILLIPS SELF DRILLING SCREWS TO MOUNT LAMPHOLSTER. -HORNET UVC LAMP ASSEMBLY LOCATED IN EXISTING DUCTWORK OUTSIDE OF AIRHANDLER. - TYPICAL EXISTING DUCTWORK PROPRIETARY AND
THE INFORMATION CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF UV
RESOURCES. ANY REPRODUCTION IN PART
OR AS A WHOLE WITHOUT WRITTEN
PERMISSION IS PROHIBITED
OTHERWISE SPECIFIED, STANDARD TOLERANCE
APPLIES TYPCIAL A-FRAME COIL
ASSEMBLY INSIDE
AIR HANDLER ENGR QA PROD DEPT -TYPICAL EXISTING AIR HANDLER APPROVAL DATE RE/ SCALE 05/22/2025 DATE NOT DRAWN TO SCALE INITIAL RELEAE -HORNET UVC LAMP ASSEMBLY LOCATED IN EXISTING DUCTWORK OUTSIDE OF AIRHANDLER. DESCRIPTION OF CHAGNE PAGE — Typical existing Ductwork DRAWING NO HORNET INSTALLATION TYPCIAL A-FRAME COIL
ASSEMBLY INSIDE
AIR HANDLER — TYPICAL EXISTING AIR HANDLER INST-57303551 <u></u>무 ω HAHN ᄧ RE/

 \supset